



PICSWR PCB underside layout for etching

To avoid DIL and SIL holes use high contrast printing  
(- printer set to Use system halftone with max gamma and  
max dot size)